



# Amsonic 400R-Series

Solvent parts cleaning systems
(Class A3 hydrocarbons or modified alcohol)



## The cleaning technology for metals, ceramics and plastics

The future belongs to the non-halogenated, without carcinogenic properties, such as A3 solvents. These solvents include hydrocarbons or modified alcohols. Amsonic is still the real pioneer regarding A3 fluids, in terms of cleaning processes, technology and cleanliness level. Their environmental performances and their very low cost of ownership are what makes A3 solvents a true alternative for most Industries.

The Amsonic 400R-Series is a compact single chamber cleaning system, with a high throughput. It uses a proven procedure that, at a high temperature, applies non-chlorinated solvents under a patented vacuum process. 400R-Series cleaning equipment can combine different cleaning steps such as vapor phase, ultrasonic cleaning, drying and distillation under vacuum (closed loop). The vacuum technology increases the cleaning efficiency and guarantees a safe operation of the machine. Options such as double ultrasonic transducers, electro polished chamber walls, micro-filtration can meet highest requirements in terms of particle counting (particle size, number and weight).

The cleaning program is chosen considering the type of soiling, the geometry of the parts and cleanliness requirements. The throughput lies



between 6 up to 12 loads per hour. The Amsonic 400R-Series is equipped with a working tank and optional with a clean tank. The distillation capacity assures a continuous availability of clean solvent. The tank volume, the heating capacity and the distiller are optimally coordinated. Several solvents can be used, e.g. Isoparaffin or modified alcohols. Integration of an Amsonic 400R-Series in a fully automated manufacturing line is possible, on option, with loading and unloading conveyor, in addition with automatic basket-covering and barcodes reader for program identification.

## Technical specifications

| Amsonic                 | 400R                         | 410R                         | 415R                         | 420R                         |
|-------------------------|------------------------------|------------------------------|------------------------------|------------------------------|
| Dimension Basket        | 37 x 22 x 20 cm              | 53 x 32 x 20 cm              | 60 x 40 x 30 cm              | 67 x 48 x 30 cm              |
| Max. Weight per charge  | 30 kg                        | 50 kg                        | 80 kg                        | 100 kg                       |
| Throughput              | 6 – 12 /h                    | 6 – 10 /h                    | 6 – 10 /h                    | 6 – 10 /h                    |
| Solvent capacity        | ca. 160 liter                | ca. 340 liter                | ca. 500 liter                | ca. 700 liter                |
| Cleaning temperature    | 60 – 80°C                    | 60 - 80°C                    | 60 – 80°C                    | 60 - 80°C                    |
| Steam temperature       | 95 – 110°C                   | 95 – 110°C                   | 95 – 110°C                   | 95 – 110°C                   |
| Electricity             | ca. 14 kW                    | ca. 17 kW                    | ca. 20 kW                    | ca. 24 kW                    |
| Compressed air          | 6 – 8 bar<br>ca. 100 Liter/h | 6 – 8 bar<br>ca. 100 Liter/h | 6 - 8 bar<br>ca. 200 Liter/h | 6 – 8 bar<br>ca. 200 Liter/h |
| Ext. dimensions (WxDxH) | 2,1 x 1,2 x 2 m              | 2,7 x 1,6 x 2,4 m            | 3 x 1,8 x 2,4 m              | 3,9 x 2 x 2,5 m              |
| Weight                  | ca. 1300 kg                  | ca. 2000 kg                  | ca. 2500 kg                  | ca. 3200 kg                  |

### PLC control with touch screen

The machine is controlled by PLC (Siemens) and a user-friendly HMI interface that includes different cleaning programs and maintenance programs such as the emptying of the distillation unit or the changing and drying of the micro filter. Access to process times and cleaning parameters are user dependent, and protected by passwords. The machine is operated by a user-

friendly touch screen; depending on the existing software options, it can be graphically visualized on the display and all relevant process data can be documented (cleaning report for track and traceability). Via a remote support, with the appropriate standard remote maintenance software, the customer support can easily be connected to the system providing online servicing.

## **Applications**


Automotive, aircraft industry, precision mechanics, turned parts, watch industry, orthopedic and dental implants, all those industrial sectors require cleanliness results at different stages, intermediate or final cleaning, prior to PVD or CVD coating, prior to plating or laser welding. All those industrial branches are using cleaning systems with Amsonic Technology.

Non chlorinated A3 solvents protect cleaned parts from corrosion. They are therefore more suitable than water base detergents in some applications. Solvents (Isoparaffin or modified alcohols) are almost indefinitely distillable. The yearly consumption, depending on the application, is approx. 50 to 200 liters.

No matter if your customers request a guarantee for surface tension or particle free parts or if you need to clean a high volume – Amsonic has long time experience with A3 solvent cleaning and will recommend the best equipment suitable for you.



### Solvent circuit





## Your centre of competence for precision cleaning



Hamo/Amsonic offers a wide range of water-based and closed circuit A3 solvent based cleaning units that provide thorough cleaning processes for various industrial sectors:

## Water-Based Precision Cleaning Equipment (Ultrasonic)

### Amsonic AquaLine / ModuLine

Hight performance-Ultrasonic-Precision-Cleaning equipment



### Water-Based Spray Cleaning systems

#### Hamo 210 / 420 / 840

Spray-cleaning and drying equipment for life sciences- and medical-devices applications

## Pharma-Conform Spray Cleaning systems (cGMP)

### Hamo PG 800 / 1300

Pharma-Conform (cGMP) Cleaning equipment in single or double door execution (Bio Seal)

### **Amsonic Hamo HPM**

High pressure cleaning systems (>80 bar) for pharmaceutical application



## Solvent-Based Precision Cleaning Equipment

### Amsonic 400 R Serie

Solvent-based Ultrasonic equipment (Class A3)
Cleaning under vacuum, above or below flash point



## **Detergents / Additives**

### Amsonic PreciClean / Hamo liquid

Water based detergents



### Switzerland:

**Amsonic AG (Headquarter)**CH-2504 Biel/Bienne

#### Germany:

Amsonic GmbH

D-78467 Konstanz

### France:

**Amsonic SAS** 

F-69970 Chaponnay/Lyon

Phone: +41 (0)32 344 35 00 amsonic.ch@amsonic.com

Phone: +49 (0)7531 122 180 amsonic.de@amsonic.com

Phone: +33 (0)437 28 18 00 amsonic.fr@amsonic.com

08.17/MW